

FLOORING TRANSITION INSTALLATION

Installing a Framera transition is fairly simple...



Step 1: To start, cut your track and moulding to the appropriate size.



Step 2: Screw the track to the subfloor. Make sure you leave $\frac{1}{4}$ " between your floor and the track to allow for floor expansion. We recommend pre-drilling the holes.



Front View



Zoomed In View

Step 3: Beginning on one side, align the stem of the moulding with the track.



Step 4: Using the palm of your hand, firmly press the transition into the track. Continue to inch your way down the moulding pressing it into the track as you go. Keep the moulding in-line with the track as you move from one end to the other.



Step 5: After the transition is completely in the track, it should be flush with your floor. If it is not, use a rubber mallet to insure that the transition is tight.